

KRYLEX®
Adhesives and sealants

KB164
Instant Adhesive
(Cyanoacrylate)

Document No:	KX-01-600-2261
Issue:	1
Amendment:	a
Date:	29.02.2012
Page	1 of 2

TECHNICAL DATA

PRODUCT DESCRIPTION

KRYLEX® KB164 is a medium-high viscosity ethyl cyanoacrylate adhesive. KB164 is suitable for bonding a very wide range of materials, including some porous ones, where very fast cure speed is required.

TYPICAL APPLICATIONS

KRYLEX® KB164 is specially formulated to give superior bonds on common substrates. CS Grades work on acidic and porous substrates where other cyanoacrylates fail to bond. Will bond wood, cork, leather, cardboard and similar surfaces. KB164 relies less on surface moisture for cure speed than standard cyanoacrylates. KB164 has enhanced gap filling capacity.

PROPERTIES OF MATERIAL

	Value
Chemical type	Ethyl
Appearance	Clear Liquid
Specific Gravity	1.10
Viscosity ¹	cPs 1275-1650
Typical Value	cPs 1500
Tensile Strength ²	(N/mm ²) 21
Fixture Time	(secs) 5-60
Full Cure	(hours) 24
Flash Point	(°C) > 85
Shelf Life @ 5°C	(months) 12
Max Gap Fill	(mm) 0.20
Temperature Range	(°C) Continuous -50 to +80

¹ Brookfield LVF, spindle 3, 30rpm

² ISO 6922

CURING PERFORMANCE

Typical Speed:

Steel/steel	<60 seconds
ABS/ABS	<20 seconds
Rubber/Rubber	<15 seconds
Wood (balsa)	<3 seconds

Cure speed vs. substrate

The speed of cure of cyanoacrylates varies according to the substrates to be bonded. Acidic surfaces such as paper and leather will have longer cure times than most plastics and rubbers. Some plastics with very low surface energies, such as polyethylene, polypropylene and Teflon® require the use of **KRYLEX®** KP707 Primer (see KP707 TDS for further info).

Cure speed vs. environmental conditions

Cyanoacrylate adhesives require surface moisture on the substrates in order to initiate the curing mechanism. The speed of cure is reduced in low humidity conditions. Low temperatures will also reduce cure speed. All figures relating to cure speed are tested at 21°C.

Cure speed vs. bond gap

KRYLEX® cyanoacrylates give best results on close fitting parts. The product should be applied in a very thin line in order to ensure rapid polymerisation and a strong bond. Excessive bond gaps will result in slower cure speeds.

Cure speed vs. activator

KRYLEX® KP4527 Activator may be used in conjunction with **KRYLEX®** cyanoacrylates where cure speed needs to be accelerated. Cure speeds of less than 2 seconds can be obtained with most **KRYLEX®** cyanoacrylates.

The use of an activator can reduce the final bond strength by up to 30% - Chemence recommends testing on the parts to measure the effect.

ENVIRONMENTAL RESISTANCE

Hot strength

KRYLEX® cyanoacrylate adhesives are suitable for use at temperatures up to 80°C. At 80°C the bond will be approximately 70% of the strength at 21°C. The bond strength at 100°C is approximately 50% of full strength at 21°C.

Heat ageing

KRYLEX® cyanoacrylates retain over 90% of their strength when heated to 80°C for 90 days and then tested at 21°C. Heating the bond to 100°C and then testing at 21°C gives bond strength of approximately 50% of initial strength.

Chemical / Solvent Resistance

KRYLEX® cyanoacrylates exhibit excellent chemical resistance to most oils and solvents including motor oil, leaded petrol, ethanol, propanol and freon. Cyanoacrylates are not resistant to high levels of moisture or humidity over time.

REMOVAL OF CURED CYANOACRYLATE

Cured cyanoacrylate may be removed from most substrates, and parts disassembled, with **KRYLEX®** KP687 Debonder. It is not possible to fully remove cyanoacrylate from fabrics.

GENERAL INFORMATION

For safe handling of this product consult the Material Safety Data Sheet.

STORAGE

Store in a cool area out of direct sunlight

Refrigeration to 5°C gives optimum storage stability.



KB164
*Instant Adhesive
(Cyanoacrylate)*

Document No:	KX-01-600-2261
Issue:	1
Amendment:	a
Date:	29.02.2012
Page	2 of 2

TECHNICAL DATA

DIRECTIONS FOR USE

Bond speed is very fast so ensure that parts are properly aligned before bonding.

KRYLEX® KP4527 Activator may be required if there are gaps or porous surfaces.

Some plastics may require application of **KRYLEX**® KP707 Primer.

Ensure parts are clean, dry and free from oil and grease. Product is normally hand applied from the bottle. Apply sparingly to one surface and press parts firmly together until handling strength is achieved. As a general rule, as little cyanoacrylate as possible should be used – over application will result in slow cure speed and lower bond strength.

Please contact your **KRYLEX**® representative for further advice on dispensing solutions.

DATA RANGES

The data contained in this data sheet may be reported as typical value and/or range. Values are based on actual test data and are verified on a regular basis.

PRESENTATION

Bottles:20g, 50g and 500g.
Available in bulk for use with dispensing systems.

NOTES

The information contained herein is produced in good faith and is believed to be reliable but is for guidance only. Chemence Ltd and its agents cannot assume liability or responsibility for results obtained in the use of its product by persons whose methods are outside or beyond our control. It is the user's responsibility to determine the suitability of any of the products and methods of use or preparation prior to use mentioned in our literature and furthermore the user's responsibility to observe and adapt such precautions as may be advisable for the protection of personnel and property in the handling and use of any of our products.

® denotes a registered trademark.