



CE 100

PRODUCT DESCRIPTION

Chemence CE-100 Instant Superglue is a medium viscosity (100 cPs) Ethyl Cyanoacrylate based adhesive. CE-100 is suitable for bonding a very wide range of materials where fast cure speed is required.

TYPICAL APPLICATIONS

CE-100 is specially formulated for high strength, general purpose bonding of most plastics, rubbers, metals and other common substrates. Recommended for use on assemblies with close fitting parts and smooth, even surfaces.

PROPERTIES OF MATERIAL

| | | Value |
|-------------------------------|----------------------|-----------------------|
| Chemical type | | Ethyl |
| Appearance | | Clear Liquid |
| Specific Gravity | | 1.06 |
| Viscosity ¹ | cPs | 80-120 |
| Typical Value | cPs | 100 |
| Tensile Strength ² | (N/mm ²) | 20 |
| Fixture Time | (secs) | 10-30 |
| Full Cure | (hours) | 24 |
| Flash Point | (°C) | > 85 |
| Shelf Life @ 5°C | (months) | 12 |
| Max Gap Fill | (mm) | 0.15 |
| Temperature Range | (°C) | Continuous -50 to +80 |

¹ Cone and Plate Rheometer, controlled stress

² ISO 6922

CURING PERFORMANCE

Typical Speed:

| | |
|---------------|-------------|
| Steel/steel | <30 seconds |
| ABS/ABS | <20 seconds |
| Rubber/Rubber | <15 seconds |

Cure speed vs. substrate

The speed of cure of cyanoacrylates varies according to the substrates to be bonded. Acidic surfaces such as paper and leather will have longer cure times than most plastics and rubbers. Some plastics with very low surface energies, such as polyethylene, polypropylene and Teflon® require the use of Chemence LA-77 Primer (see LA-77 TDS for further info).

Cure speed vs. environmental conditions

Cyanoacrylate adhesives require surface moisture on the substrates in order to initiate the curing mechanism. The speed of cure is reduced in low humidity conditions. Low temperatures will also reduce cure speed. All figures relating to cure speed are tested at 21°C.

Cure speed vs. bond gap

Chemence cyanoacrylates give best results on close fitting parts. The product should be applied in a very thin line in order to ensure rapid polymerisation and a strong bond. Excessive bond gaps will result in slower cure speeds.

Cure speed vs. activator

Chemence Activators LA-11 and LA-12 may be used in conjunction with Chemence cyanoacrylates where cure speed needs to be accelerated. Cure speeds of less than 2 seconds can be obtained with most Chemence cyanoacrylates. The use of an activator can reduce the final bond strength by up to 30% - Chemence recommends testing on the parts to measure the effect.

ENVIRONMENTAL RESISTANCE

Hot strength

Chemence cyanoacrylate adhesives are suitable for use at temperatures up to 80°C. At 80°C the bond will be approximately 70% of the strength at 21°C. The bond strength at 100°C is approximately 50% of full strength at 21°C.

Heat ageing

Chemence cyanoacrylates retain over 90% of their strength when heated to 80°C for 90 days and then tested at 21°C. Heating the bond to 100°C and then testing at 21°C gives bond strength of approximately 50% of initial strength.

Chemical / Solvent Resistance

Chemence cyanoacrylates exhibit excellent chemical resistance to most oils and solvents including motor oil, leaded petrol, ethanol, propanol and freon. Cyanoacrylates are not resistant to high levels of moisture or humidity over time.

REMOVAL OF CURED CYANOACRYLATE

Cured cyanoacrylate may be removed from most substrates, and parts disassembled, with Chemence LA-68 Debonder. It is not possible to fully remove cyanoacrylate from fabrics.

GENERAL INFORMATION

For safe handling of this product consult the Material Safety Data Sheet.

STORAGE

Store in a cool area out of direct sunlight. Refrigeration to 5°C gives optimum storage stability.



TECHNICAL

DIRECTIONS FOR USE

Bond speed is very fast so ensure that parts are properly aligned before bonding.

Chemence Activators may be required if there are gaps or porous surfaces. Some plastics may require application of Chemence LA-77 Primer.

Ensure parts are clean, dry and free from oil and grease.

Product is normally hand applied from the bottle. Apply sparingly to one surface and press parts firmly together until handling strength is achieved. As a general rule, as little cyanoacrylate as possible should be used – over application will result in slow cure speed and lower bond strength.

Please contact your Chemence representative for further advice on dispensing solutions.

PRESENTATION

- Tubes:.....2g, 3g, 4.5g
- Bottles:.....5g, 20g, 50g, 500g
- Bulk

DATA RANGES

The data contained in this data sheet may be reported as typical value and/or range. Values are based on actual test data and are verified on a regular basis.

NOTES

The information contained herein is produced in good faith and is believed to be reliable but is for guidance only. Chemence Ltd. and its agents cannot assume liability or responsibility for results obtained in the use of its product by persons whose methods are outside or beyond our control. It is the user's responsibility to determine the suitability of any of the products and methods of use or preparation prior to use mentioned in our literature and furthermore the user's responsibility to observe and adapt such precautions as may be advisable for the protection of personnel and property in the handling and use of any of our products.